

SECTION 6 - MAINTENANCE AND OIL CHANGE

1. CLEANING

Wash with soap and water, rinse with clear water

Never use a pressure hose

Polish the paint finish with slightly abrasive products

Do not use silicone-based products

Use special plexiglass cleaners for the canopy

2. OIL CHANGE

Oil changes must be carried out every 50 hours.

NOTE : For the 50 and 100 hour inspections, refer to the Maintenance Manual.

---